


BRONXVILLE TO SCARSDALE GEOLOGIC CROSS SECTION

Bronxville SSW [Conceptual Model of Groundwater Flow Regime]



Impossible groundwater mound where groundwater rises, stays elevated above the underlying water table, never overflows, remains pooled and doesn't move. Hydrogeologically, groundwater must and does flow down valley from the waste site to Bronxville and the Bronx River.


Paul A. Rubin
 HydroQuest
 414 E. Kerley
 Corners Road
 Tivoli, New York 12583
 845-657-8111
hydroquest@yahoo.com

Vert. Exag.: 72X